

# **ASSEMBLY INFORMATION**

### for the

## **Push Open Piston Nickel**

### **Contents:**

•	Parts Required	2
•	Assembly of the Push Open Piston to Doors	3

Page 1 V:1.00-2019

### **Push Open Piston Nickel**

### **Parts Required**



Page 2 V:1.00-2019


### **Push Open Piston Nickel**


### **Assembly of the Push Open Piston to Doors**


- · Works with standard concealed hinges and drawers
- · Effortless opening with just a light touch
- Depth adjustment ensures reliable closing and consistent performance in cases of inaccurate drilling
- · 'Safety click' feature for easy detachment of the mechanism from the mounting plate

Drilling pattern


Dimensions









Positioning



Close to the 'touch opening point' on the side opposite to hinges



On the cabinet side; gap between drawer and cabinet side = min 12mm



On the drawer bottom; in the middle of drawer

Push latch works with standard hinges.

Push latch works on drawer; the gap between the drawer and the cabinet side = min. 12 mm



MACHINERY - MATERIALS - COMPONENTS - ADHESIVES - FOILS - PANELS - DOORS

### **NEY Ltd (Head Office)**

Stonebridge Trading Estate Sibree Road Coventry CV3 4FD

t 024 7630 8100

**f** 024 7630 8101

e sales@ney.co.uk

#### **NEY Ireland**

Unit 22 Blaris Ind Estate Altona Road Lisburn BT27 5QB

t 028 92 673 000

**f** 028 92 672 999

e ireland@ney.co.uk

#### **NEY Scotland**

Block 2 Units 1-2-3 Bandeath Ind Est Throsk, Stirling FK7 7NP

t 01786 814 814

**f** 01786 814 812

e scotland@ney.co.uk