





Technical information
Explosion drawing and parts list

EB10C (5100000) EB10C / EB10 EDGE BANDER | BASE ASS'Y | Version E

Pos.	Serial No.	Code	Description	Quantity
1		3774011	CUP SQUARE NECK BOLT M.6X15	2
2		6673010	FLAT HD. SCREW M.5X8 PH.	4
3		1623040	PRESSER HOLDER	1
4		1623043	PRESSER SPRING	1
5		1623041	PRESSER CLAMP	1
6		9075003	HEX. SOCKET HD. CAP SCREW M.8X35	2
7		3833085	WASHER D.8X25X3	2
8		3833082	PANEL HOLDER	1
9		3821046	ARM NUT	2
10		3821049	PANEL HOLDER ARM	2
11		3803011	GUIDE	1
12		8070027	PAN HD. TAPPING SCREW 12X1/2 PH.BZ.	14
13		1619014	WARNING LABEL	1
14		9999998		2
15		9999998		1
16		4383009	WASHER D.10.5	1
17		6346061	ON/OFF LIGHT	1
18		5168119	POTENTIOMETER 100K	1
19		1672008	SCREW M.4X10 PH.	2
20		6368031	SWITCH	1
21		1668067	POTENTIOMETER KNOB	1
22		1324040	FELT PACKING	1
24		7089007	WING NUT M-6	2
25		3800026	FURNITURE ASS'Y	1
26		1650024	STRIP ROLL LOADER	1
27		1689023	RIVET D.3X6	12
28		3821062	STOP RING	1
29		1675031	HEX. SOCKET SET SCREW M.6X10	1
30		1650069	LOADER HOLDER ASS'Y	1
33		9999998		1
34		1615018	FOOT PEDAL ASS'Y	1
35		1426051	SPRING	2
36		3819089	NAME PLATE	1
36		5119088	NAME PLATE	1
37		3816016	WARNING LABEL	1
38		1580017	WASHER D.6.2X21X2	4
39		3800016	RIGHT GUIDE	1
40		3800020	LEFT GUIDE	1
41		5023670	RIGHT LEG	1
42		5023669	LEFT LEG	1
43		3833089	BACK PLATE	1
44		5146062	FRONT TABLE	1
45		2280004	WASHER D.5.2X11.1X0.7	8
46		4468074	SOCKET ADAPTER	1
47		0990068	JOINT	1
48		2070009	PAN HD. TAPPING SCREW 10X3/4 PH.B.	2
49		3834099	LOWER PROTECTION	1
50		4468072	SOCKET (230 V)	1



Technical information
Explosion drawing and parts list

EB10C (5100000) EB10C / EB10 EDGEBANDER | BASE ASS'Y | Version E

51	6319091	LABEL	1
52	3846066	MAIN SWITCH	1
53	3804055	PROTECTOR	1
54	3869001	MICROSWITCH	1
55	3850091	WIRING ASS'Y	1
56	3899066	CLAMP (P)	5
57	3899067	CLAMP (G)	2
58	3899070	CLIP	1
59	1680026	WASHER D.4.3 DIN125	1
60	2385005	HEX. NUT M.4	1
62	5119102	EB10C LABEL	1
63	3819101	LABEL	1
64	9574001	CUP SQUARE NECK BOLT M.5X15	6
65	7085008	HEX. NUT M.5	6